

There are two methods to let driver into WIFI certification testing mode. Depending on your needs, you can choose one of them. The WIFI certification testing mode is only for WIFI certification.

**(1) Method 1: Entering WIFI certification testing mode when you execute “insmod” command.**

**Adding the “rtw\_wifi\_spec=1” parameter when inserting driver module.**

```
$> insmod 8192cu.ko rtw_wifi_spec=1  
or  
$> insmod 8192du.ko rtw_wifi_spec=1
```

**(2) Method 2: Modifying the configuration in the Makefile when you compile the driver.**

**Editing the Makefile and set the “**CONFIG\_WIFI\_TEST**” to **y**, then recompiling the driver.**