

# MONOPRICE®

*Best Quality Products at the Lowest Price - Always!*

11701 6th Street, Rancho Cucamonga, CA 91730

Tel: (909) 989-6887 Fax: (909) 989-0078

 <http://www.monoprice.com/>

Product ID: 9407

Aero-D Aluminum Edge Cover for iPhone® 4/ 4S

## Included in the Package:

- 1x Assembled Aero case
- 1x Allen wrench
- 2x Volume button extensions
- 1x Mute switch extension
- 1x Power button extension
- 1x Sheet of self-adhesive foam pads

1. Verify that your Aero case came with all the parts listed above. If any piece is missing, please contact Monoprice Customer Service for a replacement case.
2. Use the Allen wrench to remove the two screws holding the case together.
3. Attach an adhesive pad to each corner of the smaller part of the Aero case, as shown below. Ensure that the adhesive pad does not extend over the openings at the edges of the corners. The adhesive pads ensure that the case fits tightly onto the phone and provide some amount of shock absorption.
4. Attach an adhesive pad to each corner of the larger part of the Aero case, as shown below. Leave about 1 mm space between the edge of the pad and the edge of the mute button opening.
5. Apply additional pads into the inside of the two case pieces to provide additional cushioning, as desired. Be sure not to cover any of the openings.
6. Hold the large Aero case part with the opening up, as shown below.
7. Insert the two volume button extensions into the Aero case. Insert the button extensions from the inside so that the extensions will not fall out when the case is assembled. See the illustration below.
8. Insert the mute switch extension into the rectangular opening in the case from the inside, as shown below.
9. Insert the power button extension into the appropriate opening in the case from the inside, as shown below.
10. Slide your iPhone 4 or 4S into the case, as shown below.
11. Put the other part of the case onto the exposed side of your iPhone.
12. Grip the sides of the case to ensure a tight fit. Insert the two case screws into openings on the back and tighten the screws down using the Allen wrench.
13. Keep the remainder of the adhesive pads and the Allen wrench in case you need to remove the case and reinstall it again at a later time.

Congratulations! Your Aero case and iPhone are now ready for use!

Copyright © 2001-2012 Monoprice, Inc. All rights reserved.

All trademarks are the sole property of their respective companies. All prices and specifications are subject to change without notice. Monoprice is not responsible for typographical errors. All typographical errors are subject to correction.