

MONOPRICE®

MP-S111-0882

Bluetooth Pocket Keyboard Case

User's Manual



Version 1.1

ID NO: PAKL-231E2701-00

About This Manual

This manual is designed to assist you in installing and using the Bluetooth Keyboard. Information in this document has been carefully checked for accuracy; however, no guarantee is given in this regard. The information in this document is subject to change without notice.

Edition

2nd Edition,

Copyright

© Copyright 2011-2012

This document contains proprietary information protected by copyright. All rights are reserved. No part of this manual may be reproduced by any mechanical, electronic or other means, in any form, without prior written permission of the manufacturer.

Trademarks

All trademarks and registered trademarks are the property of their respective owners.

FEDERAL COMMUNICATIONS COMMISSION

STATEMENT

You are cautioned that changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This Equipment has been tested and found to comply with the limits for a class B digital device, pursuant to Part 15 of the Federal Communications Commission (FCC) rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause

harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- ◆ Reorient or relocate the receiving antenna.
- ◆ Increase the separation between the equipment and receiver.
- ◆ Connect the equipment into a power outlet on a circuit different from that to which the receiver is connected.
- ◆ Consult the dealer or an experienced radio/TV technician for help.

Operation is subject to the following two conditions:

- 1) This device may not cause interference, and

2) This device must accept any interference, including interference that may cause undesired operation of the device.

FCC RF Radiation Exposure Statement:


This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. End users must follow the specific operating instructions for satisfying RF exposure compliance. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

System Requirements:

iOS


Installation Process:

Insert the phone into the case:



Device pairing:

1. Turn on the phone's Bluetooth discovery mode.
2. Turn on the keyboard power and press the "CONN" button. (Please make sure the blue LED is flashing)



3. You will see the device "Bluetooth Keyboard" on your phone. Choose "Connect".
4. Input the pin code that displays on your phone then press "Enter".
5. Your Bluetooth keyboard is now ready for use!

Note: 1. After 30 minutes of non-operation, the keyboard will go into sleep mode. Press any key to wake it up.

2. After the keyboard has been powered off then back on, press any key to reconnect.

Hot key function:

Note: The characters or functions represented in blue on the button require the use of the "Fn" key to produce that character or enable that function.

Function Name		Function Description
	Language	Change the input language.
	Keyboard	Call the virtual keyboard.
	Menu	Back to main screen.
	Play/Pause	Switches between Play and Pause. Once Pause is pressed, pressing this button again resumes play.
	V-	Decreases the device's sound volume. Hold down to decrease volume more quickly.

	V+	Increases the device's sound volume. Hold down to increase volume more quickly.
	Mute	Mutes the device's sound volume. Press it again to turn the system volume back on.
	Next track	Switches to the next media track. Press once for each subsequent media track.
	Pre-track	Switches to the previous media track. Press once for each preceding media track.

The "Control", "Option", and "⌘" are not functional with the US keyboard layout.

Removing the Phone:



Rechargeable Battery:

- ◆ Before use, please charge the battery until the red LED turns off.
- ◆ Power On: Press any key to reconnect. Wait for the LED to stop flashing before use.