

# MONOPRICE

## Bicycle Repair Stand

P/N 21555

### Quick Start Guide

## PACKAGE CONTENTS

Please take an inventory of the package contents to ensure you have all the items listed below. If anything is missing or damaged, please contact Monoprice Customer Service for a replacement.

- 1x Bicycle Stand
- 1x Bicycle Frame Clamp
- 1x Parts Tray
- 1x Quick Start Guide



## ASSEMBLY

1. Spread the legs on the **Bicycle Stand** and place it on the floor.
2. Release the silver quick release clamp at the top of the stand, then insert the **Bicycle Frame Clamp**. Close the quick release clamp. *Note that the frame can be oriented to hold the crossbar, the down tube, or the seat tube.*
3. Release the two black quick release levers, then extend the stand to the desired height. Close the quick release levers to lock the stand in place.
4. Turn the blue knob on the **Bicycle Frame Clamp** counterclockwise to open the clamp jaws.
5. Lift the bicycle, then place the frame member in the blue jaws of the frame clamp. Tighten the blue knob to close the jaws to hold the bicycle securely in place.
6. Clamp the **Parts Tray** to the stand, if desired.

