



PRODUCT DIMENSIONS



Commercial Series

Menu Board Ceiling TV Mount for Screens
between 10in to 40in, Max Weight 66 lbs,
VESA Patterns up to 100x100



P/N 39655	VESA: 75x75 100x100	40" MAX	30 kg (66 lbs) RATED
-----------	---------------------	---------	----------------------

SAFETY GUIDELINES


Please read this entire manual before using this device, paying extra attention to these safety warnings and guidelines. Please keep this manual in a safe place for future reference.

- Do not exceed the rated weight limit. Doing so can cause the mount to fail, resulting in equipment damage and/or severe personal injury.
- Ensure that the structure to which this mount will be installed is capable of supporting at least four times the total weight of the mount and any connected displays.
- Use the supplied mounting screws. Tighten the screws using the appropriate tool, but take care not to over-tighten them.
- This device is intended for indoor use only.
- This device contains small parts that could pose a choking hazard to small children. Keep this device and its spare parts out of reach of children.
- Inspect the installation at least once every three months to ensure that it is secure and safe to use.
- Please take an inventory of the package contents to ensure you have all the items shown in the Parts List. If anything is missing or damaged, please contact Monoprice Customer Service for a replacement.
- Make sure that mounting screws are abchored into the center of joists/studs. The use of a stud finder is highly recomended.
- Always attach concrete anchors directly to load-bearing concrete.
- Never attach concrete anchors to concrete covered plaster, drywall, or other finishing material. If mounting to covered concrete surfaces is unavoidable, the finishing surface must be counterbored described in this manual. Be sure concrete anchors do not pull away from concrete when the screws are tightened.


CUSTOMER SERVICE

The Monoprice Customer Service department is dedicated to ensuring that your ordering, purchasing, and delivery experience is second to none. If you have any problem with your order, please give us an opportunity to make it right. You can contact a Monoprice Customer Service representative through the Live Chat link on our website www.monoprice.com or via email at support@monoprice.com. Check the website for support times and links

REQUIRED TOOLS (Not Included)




OPTIONAL TOOLS




4

Secure the display with the same screws previously used in Step 2. Adjust positioning of the ceiling mount to a suitable force with the allen wrench (F).



5


Adjusting the TV to the desired position and locking it with the allen wrenches(F).



Installation & Adjustment of the screen

1

Start by pulling the arm up to 90 degrees




2

Insert two of the Phillips pan head screw into the TV. The screw will vary based on the TV's requirement. The spacer (F) can be used for recessed mounting.

B/C

D/E

F




NOTE: The Spacer (F) for screen with recess fixing (just for your need)

NOTE: The screw should protrude 0.12" (3mm) from the TV.

3

Sliding the TV into two slots in the bracket.



PACKAGE CONTENTS
Please take an inventory of the package contents to ensure you have all the items shown in the Parts List. If anything is missing or damaged, please contact Monoprice Customer Service for a replacement.

AA	Bracket	1	
A	Magentic Spirit Level	1	15x15x40
B	philips pan head screw	4	M4x12
C	philips pan head screw	4	M4x25
D	philips pan head screw	4	M5x12
E	philips pan head screw	4	M5x25
F	Spacer	4	φ9.0×φ5.0×8
	Allen wrench	1	M4
	Allen wrench	1	M5
G	washer	4	φ16xφ6.2x1.5
	Hex bolt screw	4	M6x50
H	Expansion pipe	4	M8x50

A




Magentic Spirit Level(x1)

B



Philips Pan head screw M4x12(x4)

C




Philips Pan head screw M4x25(x4)

D



Philips Pan head screw M5x12(x4)

E



Philips Pan head screw M5x25(x4)

F

+

Spccer φ9.0×φ5.0×8(x4)

Allen wrench M4/M5(x1)


G

+

Hex bolt screw M6x50 (x4)


washer φ16xφ6.2x1.5(x4)

H



Expansion pipe M8x50 (x4)

AA





bracket

Install to Solid Wood Ceiling

⚠ WARNING

- Tighten wood screws so that ceiling plate is firmly attached, but do not overtighten. Overtightening can damage the screws, greatly reducing their holding power.
- Make sure that mounting screws are anchored into the center of the joist. The use of an "edge to edge" stud finder is highly recommended.




Install to Concrete Ceiling

⚠ WARNING

- When installing the wall mount to cinder block, verify that you have a minimum of 1-3/10" of actual solid concrete thickness in the hole to be used for the concrete anchors. Do not drill into mortar joints! Be sure to mount in a solid part of the block, generally 1" minimum from the side of the block. Cinder block must meet ASTM C-90 specifications. It is recommended that a standard electric drill set on a slow setting is used to drill the hole instead of a hammer drill to avoid breaking out the back of the hole when entering a void or cavity.
- Concrete must have a 2000 psi density minimum. Lighter density concrete may not hold the concrete anchor.
- Make sure that the supporting surface will safely support the combined load of the equipment and all attached hardware and components.

A Use wall bracket of (AA) as template to mark mounting holes. Drill four 3/10" (8 mm) dia. holes 2.2" (56 mm) deep. Insert concrete anchor (H) in holes flush with the wall as shown (right). Place wall plate over anchors and secure with M6x 50 screws (G) and Washer (G). Level, then tighten all fasteners.



⚠ WARNING

- Always attach concrete anchors directly to load-bearing concrete.
- Never attach concrete anchors to concrete covered with plaster, drywall, or other finishing material. If mounting to concrete surfaces covered with a finishing surface is unavoidable, the finishing surface must be counterbored as shown below. Be sure concrete anchors do not pull away from concrete when tightening screws. If plaster/drywall is thicker than 5/8", custom fasteners must be supplied by the installer.

