





Monoprice™ Commercial Series
Rolling Stand for Landscape Display with Storage Shelf
Fits 37" to 75" TVs

P/N **49358**
User Manual

SCAN TO
LEARN MORE



THANK YOU FOR PURCHASING THIS PRODUCT

For optimum performance and safety, please read these instructions carefully before assembling, using, or adjusting this product.

SAFETY WARNINGS AND GUIDELINES

Please read this entire instruction manual before you start assembly and installation, paying extra attention to these safety warnings and guidelines. If you have any questions regarding any of the instructions or warnings, contact your local distributor for assistance. Please keep this manual in a safe place for future reference.

- Failure to read, thoroughly understand, and follow all instructions can result in serious personal injury, damage to equipment, or voiding of factory warranty.
- Make sure that the mounting surface will safely support the combined weight of the equipment and all attached hardware and components.
- DO NOT EXCEED THE MAXIMUM LISTED WEIGHT CAPACITY. Use with products heavier than the rated weights indicated may result in instability causing possible injury.
- Always use an assistant or a mechanical lifting device to safely lift and position heavy products.
- Safety gear and proper tools must be used. This product should only be installed by professionals.
- Tighten screws firmly, but DO NOT OVERTIGHTEN. Overtightening can cause product damage that greatly reduces the holding power.
- This product is intended for indoor use only. Using this product outdoors could lead to product failure and personal injury.
- Keep a clear area and distance from moving parts when using the product.
- Use only as intended. Never stand, hang, or climb on the product.
- Do not attempt to modify or reconstruct the product.
- This product may contain small items that could be a choking hazard if swallowed. Keep children away unless the product is intended for their use, and all instructions and manuals are fully reviewed and understood by them.
- Ensure that you have received all parts according to the component checklist prior to installation. If any parts are missing or faulty, contact your place of purchase for a replacement.
- Check that the product is secure and safe to use at regular intervals (at least every three months).

INTRODUCTION

Upgrade your display setup with the Rolling Stand for Landscape Display with Storage Shelf, a mobile and space-saving solution designed for effortless positioning in commercial and professional environments.

Designed to support 37" to 75" flat or curved displays, it holds up to 110 lb (50 kg) and accommodates VESA mounting patterns from 200x200 to 600x400, delivering broad compatibility. Its sturdy construction ensures consistent stability and reliable performance for larger screens.


Equipped with a convenient storage shelf rated up to 11 lb (5 kg), this stand provides space for media devices and presentation accessories. Smooth-rolling casters enable easy transport and repositioning, making it an excellent choice for offices, classrooms, conference rooms, and other dynamic display applications.


FEATURES

- Compatible with 37" to 75" flat or curved displays
- Supports a maximum TV weight capacity of 110 lb (50 kg)
- Supports a maximum DVD player weight capacity of 11 lb (5 kg)
- Compatible with VESA mounting patterns: 200x200, 300x200, 300x300, 400x200, 400x300, 400x400, 600x400


PACKAGE CONTENTS

Please take an inventory of the package contents to ensure you have all the items listed below. If anything is missing or damaged, please contact Monoprice Customer Service for a replacement.






E (x1)



F (x2)



G (x2)



H (x2)



I (x2)



J (x4)
M6



K (x4)
D6
Metal Washer




L (x4)
D6
Plastic Washer




M (x3)
D8



N (x2)
M5x10



O (x8)
M6x16



P (x3)
M8x20




Q (x1)
10-12mm




R (x1)
4mm




S (x1)
5mm



M-A (x4)
M6x14




M-B (x4)
M8x16



M-D (x4)
M8x35




M-E (x4)
D8



M-C (x4)
M6x30




M-F (x4)
Ø15xØ8x5




M-G (x4)
Ø15xØ8x15

ASSEMBLY AND INSTALLATION


1




2





3







4





5





6






7



8



Note: If the display does not stop at your desired position, adjust the two side screws alternately using the tools as shown.



CUSTOMER SERVICE

The Monoprice Customer Service department is dedicated to ensuring that your ordering, purchasing, and delivery experience is second to none. If you have any problems with your order, please give us an opportunity to make it right. You can contact a Monoprice Customer Service representative through the Live Chat link on our website **www.monoprice.com** or via email at **support@monoprice.com**. Check the website for support times and links.

TECHNICAL SUPPORT

Monoprice is pleased to provide free, live, online technical support to assist you with any questions you may have about installation, setup, troubleshooting, or product recommendations. If you ever need assistance with your new product, please come online to talk to one of our friendly and knowledgeable Tech Support Associates. Technical support is available through the online chat button on our website **www.monoprice.com** or through email by sending a message to **tech@monoprice.com**. Check the website for support times and links.

To download the latest drivers, firmware, manuals, etc., go to **www.monoprice.com** and type **49358** into the search bar. If available, support files are linked at the bottom of the product page.

DISPOSAL AND RECYCLING INFORMATION



The symbol indicates that this product should be disposed of separately from regular household waste streams. It is your responsibility to dispose of this and other electrical and electronics products via designated collection facilities appointed by the government or local authorities. Correct disposal and recycling will help prevent potential negative consequences to the environment and human health. For more detailed information about the disposal of your unwanted product, please contact your local authorities, waste disposal service, or the shop where you purchased the product.

Monoprice™ and all Monoprice logos are trademarks of Monoprice Inc.

VESA® is a registered trademark of the Video Electronics Standards Association.



TECHNOLOGY AT PRICES THAT MAKE SENSE

www.monoprice.com

Need Help? We're here for you!

Contact us: www.monoprice.com/contactus

Product pictures are for reference only.

Specifications described in this manual are subject to change without prior notification.

Monoprice™ and all Monoprice logos are trademarks of Monoprice Inc.

Copyright © 2026 Monoprice, Inc. All rights reserved.

Monoprice, Inc.

1 Pointe Drive, Suite 400

Brea, CA 92821 – USA

www.monoprice.com