



AC-2 True Bypass Analog Chorus Guitar Effect Pedal

P/N 600034


Quick User Guide

SPECIFICATIONS

Model	600034
Effect Type	Classic vintage chorus with true bypass
Input Impedance	1 M Ω
Output Impedance	1 k Ω
Rate Control	1 ~ 10 Hz
Current Draw	7.7mA
Input Power	9 VDC battery or AC power adapter
Dimensions	4.3" x 2.4" x 2.1" (110 x 60 x 53 mm)
Weight	7.9 oz. (225g)

PRODUCT OVERVIEW

1. **DC IN:** DC barrel connector for connecting an optional 9 VDC AC power adapter (not included). The internal battery is switched off when using an AC power adapter.
2. **LED:** The LED illuminates when the effect is active. Replace the battery if the LED goes dim or does not illuminate.
3. **RATE:** Rotate the knob to adjust the chorus rate.
4. **DEPTH:** Rotate the knob to adjust the chorus depth.
5. **OUT:** 1/4" TS output jack for connecting an amp or another pedal.
6. **IN:** 1/4" TS input jack for connecting a guitar or a previous pedal. Note that when a plug is inserted, the pedal is automatically turned on. When the pedal is not in use, unplug all connections to conserve battery power.
7. **FOOT SWITCH:** Step on the switch to turn the effect on or off. When the effect is on, the LED illuminates.



BATTERY INSTALLATION

1. Remove the four screws that hold the battery compartment cover in place on the underside of the pedal, then remove the cover.
2. If a battery is already installed, remove it.
3. Connect the new battery, then insert it into the battery compartment.
4. Position the cover over the battery compartment, then secure it in place using the four screws removed in step 1.

Monoprice™, Indio™, the Indio logo, and all Monoprice logos are trademarks of Monoprice Inc.