



**Stage Right by Monoprice Ellipsoidal Aluminum Replacement
Gobo Holder B Size Metal or Glass**

P/N **612100**
Quick Setup Guide

Stage Right by Monoprice Ellipsoidal Aluminum Replacement Gobo Holder B Size Metal or Glass

DESCRIPTION:

- Type "B" Sandwich Gobo Holder
- Material: Aluminum
- Color: Black
- Size: Length 3.66" x 8.58" (93 x 218 mm)
- Diameter for hold: 2.75" (70mm)
- Use with: 612751 or 612752

NOTE: Safe to use with Metal, Glass, or 3D printed Gobos. 3D printed gobos are only safe to use with LED ellipsoidal fixtures such as our Stage Right 612751 and 612752.

Steps:

- 1 Take the gobo (the metal or glass pattern you wish to project).
- 2 Loosen the screw(s) on the gobo holder to allow the gobo to fit inside.
- 3 Place the gobo into the gobo holder, ensuring it sits flat and is properly aligned. Tighten the screw(s) on the gobo holder to secure the gobo in place.

