



**Stage Right™ by Monoprice™**  
**200 W COB LED Ellipsoidal with Gobo Holder, White, 3200 K**

P/N **612752**  
Quick Setup Guide


This light fixture features a single, 200-watt white LED, a 19° beam angle, and is capable of producing up to 4300 lux at 3200 K. It allows for manual control of the beam size (using four independently adjustable shutters), focus, as well as 3-channel DMX512 control over the dimmer and strobe. It includes a built-in strobe program and can be configured as a DMX slave light.

#### Features:

- 200-watt 3200 K white LED
- 19° beam angle
- Up to 4300 lux at 4 meters
- Adjustable beam size using four independently adjustable shutters
- Manual focus control
- 3-channel DMX control
- Built-in strobe program
- NAC3 power input and pass-through output

#### Steps:

- 1 Take the gobo (the metal or glass pattern you wish to project).
- 2 Loosen the screw(s) on the gobo holder to allow the gobo to fit inside.
- 3 Place the gobo into the gobo holder, ensuring it sits flat and is properly aligned. Tighten the screw(s) on the gobo holder to secure the gobo in place.



- 4 Loosen screw 1.
- 5 Loosen screw 2.
- 6 Slide the cover parallel to the slot to access the holder compartment.
- 7 Carefully insert the gobo holder into the slot on the light fixture. Ensure it is fully seated and aligned according to the fixture's design.
- 8 Tighten the screws to secure the gobo holder within the fixture.