

# Music Receiver

## User's Manual

Model: VW-MR01

### Product Profile:

The Music Receiver simply connects to the Line-In or Aux port on your home speaker system, you can then stream audio from your Bluetooth enabled cell Phone or MP3 player to your speaker system. Enjoy The convenience of having your music source in the Palm of your hand and listening to it through your home Stereo.

### Package Contents:

- Music Receiver
- USA / EU Standard Plug
- User's Manual
- RCA audio cable
- 3.5 to 3.5MM audio cable

### Requirements:

1. A Bluetooth enabled cell phone, PC, Laptop, PAD, MP3 player or other music source that supports the Bluetooth A2DP and AVRCP profiles.

2. A portable music player or home system that has a RCA connection for line-in or Aux-in

1

### Setup:

1. Slide the power plug onto the Music Receiver

2. Connect the RCA audio cable between the Music Receiver and the home stereo speaker system

3. Plug the Music Receiver into a 110/220V outlet. The Blue light on the Music Receiver will blink

4. Pair your cell phone users guide on how to search and add a Bluetooth device. Generic instructions are:

From your cell phone:

- A. Activate the Bluetooth functionality ON.
- B. Make the device visible
- C. When the "iSpeaker" appears on your cell phone pair with the password "0000".

5. The cell phone is paired and connected with the Music Receiver when the flashing blue light on the Music Receiver turns solid blue.

2

### Operating Instructions:

The cell phone must be "reconnected" to the Music Receiver every time you come within range. To connect go to the Bluetooth menu on the cell phone and select "iSpeaker". A solid blue light on the Music Receiver indicates that the cell one is Paired, connected and will send music to the receiver. A blinking blue light indicates that a cell phone is not "Connected".

To go back to using the cell phone speaker just turn off Bluetooth on the phone momentarily.

You only need to "Pair" the cell phone to the Music Receiver once. After that you just need to "connect" to The Music Receiver, you can "pair" as many device to the Music Receiver as you would like but you can only "connect" one at a time.

At first you might wish that your cell phone would automatically connect to the Music Receiver. In the long run this would be more frustrating as all your Normal sounds (clicks, beeps etc.) would play through the stereo-or not play if the stereo isn't on.

3

### Specifications:

- Power Input: 90-240vAC/25mA
- Standby power: < 5mA
- Bluetooth standard: V2.1+EDR
- Transmission: Class 2 (10M)
- Frequency range: 2.4-2.48Ghz
- Effective range: 10M(33ft)
- Bluetooth Profiles: A2DP, AVRCP
- Isolation: > 60dB
- Signal-to-Noise: > 95dB
- Frequency response: +/- 3dB 70Hz-20KHz

### Troubleshooting:

The Music Receiver does not pair to the cell phone: Make sure the cell phone supports both AVRCP and A2DP. No connection between the cell phone and the Music Receiver.

- 1. Make sure the cell phone is close to the receiver.
- 2. Go to the cell phone Bluetooth settings and make sure it is "connected" to the "iSpeaker".
- 3. Pair the units again.

**The Sound is interrupted:** Move the cell phone closer to the Music Receiver. Bluetooth is designed to work at short distances (less than 33 feet) and walls or other obstructions will reduce the range.

4