# MONOPRICE

# Full-Size Mechanical Backlit Keyboard with Outemu Brown Switches

P/N 33539

## **Quick User Guide**



## **Function Keys**

Reset

Fn+Del	Restore keyboard default settings
(hold for 5 seconds)	Restore Reyboard default settings

#### **Backlight Keys**

Fn+ESC	S.;;OFF	Backlighting On/Off
Fn+PrtSc	11- 11- -,1 -,1	Switch LED backlight patterns (6 settings)
Fn+PgUp	<b>综十</b>	Increase Brightness
Fn+PgDn	÷.; —	Decrease Brightness
Fn++	\$ <u>`</u> ;>>>	Increase Pattern Speed (if applicable)
Fn+-	<<< >	Decrease Pattern Speed (if applicable)

#### Media Function Keys

Fn+F1	1	Media Player
Fn+F2	₫-	Volume Down
Fn+F3	<b>-</b>	Volume Up
Fn+F4	۲	Mute
Fn+F5		Stop
Fn+F6	M	Previous Track
Fn+F7	▶/	Play/Pause
Fn+F8	M	Next Track

#### **Application Hot Keys**

Fn+F9	$\boxtimes$	Launch Email App
Fn+F10	샵	Launch Web Browser
Fn+F11	₿	Lock/Unlock Keyboard
Fn+F12		Launch Calculator App

#### **Gaming Function Keys**

Fn+Windows Key	Âÿ	Disable/Enable Windows Key
Fn+W	«=»	Swap WASD and Arrow Key Functions

#### Macro Keys

Fn+Ins	•	Start/Stop Macro Recording
Fn+Macro Key (Y, U, I, O, or P)		See Macro Recording Section for Details

### Macro Recording

- 1. Press **Fn+Ins** to enter macro recording mode. The four system LEDs will begin blinking.
- 2. Select a macro to record by pressing **Fn+Macro Key** (Y, U, I, O, or P). The LEDs will stop blinking and remain lit while recording.
- 3. Type the keys to record. The macro can contain up to 31 characters.
- 4. Press **Fn+Ins** to stop recording.
- 5. Use the macro by pressing **Fn+Macro Key** (Y, U, I, O, or P).

#### **Features**

- Double injection keycaps with laser printing and white backlighting
- Compatible with Windows<sup>®</sup> 2000, XP, Vista<sup>®</sup>, Win7, Win8, Win10
- Outemu Brown switches with more than 50 million keystroke switch life
- Full anti-ghosting keys
- 5.9 foot (1.8 meter) long USB cable
- Dimensions: 17.4" x 5.6" x 1.5" (442 x 141 x 37 mm)
- Weight: 41.9 oz. ±0.9 oz. (1188g ±25g)