

Deep Blue 10 Waterproof Bluetooth Speaker (IPX-6)



User's Manual

SAFETY WARNINGS AND GUIDELINES

- This speaker is waterproof with an ingress protection rating of IPX6. This means that speaker can withstand the application of "powerful water jets" consisting of a 1/4" stream with a pressure of 30kPa, at a distance of 3 meters, at a rate of 12.5 liters per minute, for 3 minutes. While this means that the speaker is protected from water splashing or rain, it is not protected from more prolonged exposure or from being immersed in water. Do not immerse this product in water.
- Note that this product is only waterproof when the cover for the auxiliary and charging ports is properly secured. Water or moisture getting into either port can cause damage to the product.
- After this device has been exposed to water, it should be thoroughly dried before continued use.
- The device has a protective silicone sleeve, however this does not mean that it is indestructible or drop-proof. Please take care to avoid physical damage to the product.
- Do not subject the product to extreme force, shock, or fluctuations in temperature or humidity.
- Clean using a soft, dry cloth only. Do not use chemical cleaners, solvents, or detergents. For stubborn deposits, moisten the cloth with warm water.
- This device has no user serviceable parts. Do not attempt to open, service, or modify this device.
- Keep away from corrosive materials.
- Charge the battery before first use and at least once every three months.
- This device contains a Lithium-ion battery. Dispose of this device only in accordance with local, state, or federal regulations for electronic waste.

INTRODUCTION

Thank you for purchasing this Deep Blue Sea Waterproof Bluetooth® Speaker!

This speaker features a Bluetooth radio, allowing for wireless connections with your mobile devices. It is waterproof with an IPX6 rating, making it safe for use in all weather conditions. A built-in microphone allows it to be used as a hands-free communication device for making and receiving phone calls.

FEATURES

- Built-in 5-watts (RMS) per channel amplifier driving two 2" speakers
- Waterproof with an IPX6 rating
- Bluetooth radio with A2DP and AVRCP profiles
- Up to 30 feet wireless range
- 3.5mm auxiliary input for wired connections
- Built-in rechargeable Lithium-ion battery for up to 9 hours of audio playback
- 90Hz ~ 20kHz frequency response

CUSTOMER SERVICE

The Monoprice Customer Service department is dedicated to ensuring that your ordering, purchasing, and delivery experience is second to none. If you have any problem with your order, please give us an opportunity to make it right. You can contact a Monoprice Customer Service representative through the Live Chat link on our website **www.monoprice.com** during normal business hours (Mon-Fri: 5am-7pm PT, Sat-Sun: 9am-6pm PT) or via email at **support@monoprice.com**

PACKAGE CONTENTS

Please take an inventory of the package contents to ensure you have all the items listed below. If anything is missing or damaged, please contact Monoprice Customer Service for a replacement.

1x Deep Sea Blue Waterproof 10-Watt Bluetooth Speaker


1x Micro USB charging cable

1x 3.5mm TRS stereo audio cable

1x Carabiner clip

1x User's manual

PRODUCT OVERVIEW



1. Micro USB charging port
2. 3.5mm auxiliary audio input
3. Call/Play/Pause button
4. Volume decrease/previous track button
5. Power button
6. Volume increase/next track button

CHARGING

This device contains a rechargeable Lithium-ion battery, which can provide up to 9 hours of audio playback. The battery should be fully charged prior to initial use and at least once every 3 months. Perform the following steps to charge the battery in this speaker.

1. Open the cover seal on the side to reveal the charging port.
2. Using the included micro USB cable, plug one end into the micro USB port on the speaker, then plug the other end into a USB power source, such as a computer port or wall charger.
3. An LED under the front grille, next to the charging port, will glow **red** while charging is in progress. When charging is complete, the LED will turn off. Depending on the charging power of your USB power source, it takes 4-6 hours to perform a full charge.
4. When charging is complete, remove the micro USB charging cable and close the cover seal. Ensure that the seal is fully closed and properly seated to restore the waterproof status.

POWER

- To power the speaker ON, press and hold the **Power** button for about 3 seconds. The speaker will emit an ascending series of notes and the LED under the grille will illuminate blue.
- To power the speaker OFF, press and hold the **Power** button for about 3 seconds. The speaker will emit a descending series of notes and the LED under the grille will turn off.

BLUETOOTH® PAIRING

Perform the following steps to pair this speaker with your Bluetooth® enabled mobile device.

1. Press and hold the Power button for about 3 seconds to power the speaker on. The speaker will emit an ascending series of notes and the LED inside the front grille will start blinking blue, indicating that the speaker is in Bluetooth pairing mode.

If the speaker has been previously paired with a device, which is powered on, has Bluetooth turned on, and is within range, it will automatically reconnect. If you wish to pair the speaker with another device, press and hold the Power button for about 2 seconds to clear the existing pairing and put the speaker into Bluetooth pairing mode.

2. Open the settings on your mobile device, ensure Bluetooth is turned on, then perform a search for nearby Bluetooth devices.
3. When the search is completed, select the **Deep Blue Sea** entry. If you are prompted for a passcode, enter 0000 (four zeroes). The LED under the front grille will cease blinking and the speaker will sound a tone. Depending on your device, it will automatically connect. If it does not, select the entry on your mobile device to connect with the speaker.

HANDLING PHONE CALLS

- When an incoming call is received, audio playback will automatically pause and the speaker will sound a ringtone.
- Momentarily press the **Call/Play/Pause** button to answer the call.
- When the call is completed, momentarily press the **Call/Play/Pause** button to terminate the call. Audio playback will automatically resume.
- To reject an incoming call, use your phone's call reject function.

OPERATION

- Press and hold the **Power** button for about 3 seconds to power the speaker on or off.
- If the speaker is paired with an active device, press and hold the **Power** button for about 2 seconds to delete the existing pairing and put the speaker in Bluetooth® pairing mode.
- Momentarily press the **Call/Play/Pause** button to start or pause audio playback.
- When an incoming call is present, momentarily press the **Call/Play/Pause** button to answer the incoming call. When the call is complete, momentarily press the **Call/Play/Pause** button to terminate the call.
- Momentarily press the **Volume decrease/previous track** button to skip back to beginning of the current track. If already at the beginning of the track, press the **Volume decrease/previous track** button to skip back to the beginning of the previous track.
- Momentarily press the **Volume increase/next track** button to skip forward to the beginning of the next track.
- Press and hold the **Volume decrease/previous track** button to decrease the speaker's volume level.
- Press and hold the **Volume increase/next track** button to increase the speaker's volume level.

AUXILIARY INPUT

To use the speaker with non-Bluetooth® enabled devices, you can use the included audio cable to connect the headphone output of your device to the auxiliary input on the speaker. Perform the following steps to use a wired connection.

1. Open the cover seal on the side to reveal the 3.5mm auxiliary input.
2. Using the included 3.5mm audio cable, plug one end into the auxiliary input on the speaker, then plug the other end into the headphone output on your mobile device. The Bluetooth radio is disabled whenever a cable is plugged into the speaker's auxiliary input.
3. When you are finished, unplug the audio cable from the speaker and close the cover seal. Ensure that the seal is fully closed and properly seated to restore the waterproof status.

TECHNICAL SUPPORT

Monoprice is pleased to provide free, live, online technical support to assist you with any questions you may have about installation, setup, troubleshooting, or product recommendations. If you ever need assistance with your new product, please come online to talk to one of our friendly and knowledgeable Tech Support Associates. Technical support is available through the online chat button on our website **www.monoprice.com** during regular business hours, 7 days a week. You can also get assistance through email by sending a message to **tech@monoprice.com**

SPECIFICATIONS

Model	14446
Drivers	Two 2" drivers
Amplifier	5-watts RMS per channel
Frequency Response	90Hz ~ 20kHz
Bluetooth® Profiles	A2DP and AVRCP
Bluetooth Range	Up to 30 feet
Built-in Battery	2200mAh Lithium-ion
Full Charge Playback Time	Up to 9 hours
Charging Time	4-6 hours
Charging Source	Micro USB (5 VDC, 1A)

REGULATORY COMPLIANCE

Radio Notice for FCC



Caution

This FCC Part 15 radio device operates on a non-interference basis with other devices operating at this frequency. Any changes or modification to said product not expressly approved by Monoprice, including the use of non-approved antennas, could void the user's authority to operate this device.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Radio Notice for Industry Canada



Caution

This IC RSS-210 radio device operates on a non-interference basis with other devices operating at this frequency. Any changes or modification to said product not expressly approved by Monoprice, including the use of non-approved antennas, could void the user's authority to operate this device.

This device complies with IC RSS-210. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

The Bluetooth word mark and logos are registered trademarks of Bluetooth SIG, Inc.