

MONOPRICE

**Bluetooth® Over-the-Ear Headphones
with External Speakers**

Model 15276

User's Manual

SAFETY WARNINGS AND GUIDELINES

- This device is intended for indoor use only.
- Do not expose this device to water or moisture of any kind. If moisture does get in or on the device, immediately power it off and do not reapply power until it has been fully dried.
- Do not expose this device to excessively high temperatures. Do not place it in, on, or near heat sources, such as a fireplace, stove, radiator, etc. Do not leave it in direct sunlight.
- This device contains a Lithium rechargeable battery. Dispose of this device only in accordance with local, state, or federal regulations for electronic waste.
- Charge the battery before first use and at least once every three months.
- Clean using a soft, dry cloth only. Do not use chemical cleaners, solvents, or detergents. For stubborn deposits, moisten the cloth with warm water.
- This device has no user serviceable parts. Do not attempt to open, service, or modify this device.
- Do not use this device while operating a motor vehicle, heavy equipment, walking in traffic, or any other situation in which situational awareness is a key to safety.

INTRODUCTION

Thank you for purchasing these Bluetooth® Over-the Ear Headphones with External Speakers!

These headphones feature a wireless Bluetooth connection, which allows you to listen to music without being tethered to your phone or mp3 player. Each earpiece contains both a headphone driver and an external speaker driver, which can be switched on to use the headphones as Bluetooth speakers. A built-in microphone allows you to safely make and receive phone calls without having to manipulate or hold your phone. The built-in rechargeable battery provides up to 8 hours of continuous playback or phone usage time.

FEATURES

- Bluetooth® v4.1 with A2DP, AVRCP, HSP, and HFP profiles
- Switchable headphone and external speaker drivers
- Built-in microphone for hands-free phone use
- 1000mAh rechargeable battery provides up to 30 hours of continuous headphone operation or up to 3 hours of continuous speaker operation
- 3.5mm line in jack for wired operation
- Battery power level shown on iOS® devices
- Automatically powers off after 5 minutes of inactivity

CUSTOMER SERVICE

The Monoprice Customer Service department is dedicated to ensuring that your ordering, purchasing, and delivery experience is second to none. If you have any problem with your order, please give us an opportunity to make it right. You can contact a Monoprice Customer Service representative through the Live Chat link on our website www.monoprice.com during normal business hours (Mon-Fri: 5am-7pm PT, Sat-Sun: 9am-6pm PT) or via email at support@monoprice.com

PACKAGE CONTENTS


Please take an inventory of the package contents to ensure you have all the items listed below. If anything is missing or damaged, please contact Monoprice.

1x Bluetooth® over-the-ear headphones with external speakers

1x Micro USB charging cable

1x User's manual

PRODUCT OVERVIEW



- 1. External Speaker LED Indicator
- 2. Headphone/External Speaker Switch
- 3. LED Indicator
- 4. Multifunction Button
- 5. Vol+ Button

- 6. Vol- Button
- 7. Micro USB Charging Port
- 8. External Speakers
- 9. Line In 3.5mm TRS Jack
- 10. Microphone

LED INDICATOR STATES

LED Indication	Function
Red blinking	The battery power level is low. Recharge the battery.
Red solid	Battery charging is in progress.
Blue solid	Battery charging is complete. Disconnect the Micro USB charging cable.
Blue blinking slowly	The headphones are connected to the Bluetooth® audio source.
Blue blinking quickly	The headphones are not connected to the Bluetooth audio source.
Red and Blue blinking alternately	The headphones are in Bluetooth pairing mode.

CHARGING

The headphones should be fully charged before first use and should be charged at least once every three months, even if they are unused during that period of time. Perform the following steps to charge the headphones.

1. Plug the included Micro USB cable into the Micro USB charging port, then plug the other end into a USB power source (e.g., computer port, wall charger, battery pack, etc.). The LED will glow **Red** while charging is in progress.
2. Once the headphones are fully charged, the LED will change to **Blue**. Unplug the Micro USB charging cable from the headphones and from the USB power source.

POWER

- Press and hold the **Multifunction** button until the LED flashes **Blue** to power the headphones on.
- Press and hold the **Multifunction** button until the LED glows **Red** to power the headphones off.

BLUETOOTH® PAIRING

Perform the following steps to pair the headphones with your phone or other Bluetooth audio source.

1. Ensure that the headphones are powered off.
2. Press and hold the Multifunction button until the LED starts blinking alternately **Red and Blue**.
3. Open the Bluetooth settings on your phone and scan for nearby Bluetooth connections.
4. Locate and select the **MP15276** entry. If prompted for a passcode, enter **0000** (four zeroes).

UNPAIRING

With the headphones powered on, simultaneously press and hold both the **Vol+** and **Vol-** buttons until the LED flashes **Red and Blue** to clear any existing Bluetooth pairings.

AUDIO PLAYBACK CONTROL

- Momentarily press the **Multifunction** button to pause or resume audio playback.
- Momentarily press the **Vol-** button to decrease the volume for audio playback and phone calls.
- Momentarily press the **Vol+** button increase the volume for audio playback and phone calls.
- Press and hold the **Vol-** button for about 3 seconds to skip back to the beginning of the current track. If already at the beginning, it will skip back to the beginning of the previous track.
- Press and hold the **Vol+** button for about 3 seconds to skip forward to the beginning of the next track.

PHONE CONTROL

- When an incoming call is received, audio playback will automatically pause and a ring tone will sound. When the call is either rejected or terminated, audio playback will automatically resume.
- When an incoming call is received, momentarily press the **Multifunction** button to answer the call.
- When an incoming call is received, press and hold the **Multifunction** button for about 2 seconds to reject the call.
- While a call is in progress, momentarily press the **Multifunction** button to terminate the call.
- Without a call in progress or an incoming call, momentarily press the **Multifunction** button twice to redial the last number dialed.
- Without a call in progress or an incoming call, press and hold the **Multifunction** button for about 1 second to activate voice dialing. Note that your phone must also support this feature.

EXTERNAL SPEAKERS

In addition to the headphone drivers, these headphones feature external speaker drivers, which allow you to share your music with other people in the room. To use the external speaker drivers instead of the headphone drivers, slide the **Headphone/External Speaker** switch to the **Speaker On** position. The adjacent LED will glow **Blue**.

To return to headphone operation, slide the switch to the **Headphone** position. The adjacent LED will turn off.

LINE IN

To use these headphones with a non-Bluetooth® device, plug one end of a 3.5mm TRS audio cable (not included) into the **Line In** jack on the headphones, then plug the other end into the headphone output of your audio device. Whenever a cable is connected, the Bluetooth radio is disabled.

TECHNICAL SUPPORT

Monoprice is pleased to provide free, live, online technical support to assist you with any questions you may have about installation, setup, troubleshooting, or product recommendations. If you ever need assistance with your new product, please come online to talk to one of our friendly and knowledgeable Tech Support Associates. Technical support is available through the online chat button on our website www.monoprice.com during regular business hours, 7 days a week. You can also get assistance through email by sending a message to tech@monoprice.com

SPECIFICATIONS

Model	15276
Bluetooth® IC	CSR 8635
Bluetooth Version	4.1
Bluetooth Profiles	A2DP, AVRCP, HSP, HFP
Bluetooth Range	Up to 32 feet (10 meters)
Bluetooth Carrier Frequency	2402 ~ 2480 MHz
Battery	1000mAh Lithium-ion
Battery Charge Cycles	300 times (discharged \geq 80%)
Battery Operating Time	Up to 30 hours for headphone mode Up to 3 hours for speaker mode
Charging Time	About 2 hours, depending on charging current
Driver Size	40mm
Nominal Headphone Rated Power	100mW
Headphone Frequency Response	100Hz ~ 9kHz
Headphone Sensitivity	113dB \pm 3dB
Headphone Impedance	32 ohms
Nominal Speaker Rated Power	3W
Speaker Frequency Response	180Hz ~ 13kHz
Speaker Sensitivity	89dB \pm 3dB
Speaker Impedance	4 ohms
Microphone Sensitivity	-38dB \pm 3dB
Operating Temperature	+23 ~ +113°F (-5 ~ +45°C)
Storage Temperature	-40 ~ +158°F (-40 ~ +70°C)
Weight	About 7.9 oz. (225 g)

REGULATORY COMPLIANCE

Notice for FCC



This device complies with Part 15 of the FCC rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Modifying the equipment without Monoprice's authorization may result in the equipment no longer complying with FCC requirements for Class B digital devices. In that event, your right to use the equipment may be limited by FCC regulations, and you may be required to correct any interference to radio or television communications at your own expense.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Radio Notice for FCC

Caution

This FCC Part 15 radio device operates on a non-interference basis with other devices operating at this frequency. Any changes or modification to said product not expressly approved by Monoprice, including the use of non-approved antennas, could void the user's authority to operate this device.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Notice for Industry Canada

This Class B digital apparatus complies with Canadian ICES-003.

Cet appareil numérique de la classe B est conforme à la norme NMB-003 du Canada.

EU Declaration of Conformity

We, Monoprice Inc., declare that the radio equipment is in compliance with Radio Equipment Directive (RED) 2014/53/EU.

The full text of the EU Declaration of Conformity is available at the following internet address:

https://www.monoprice.com/product?c_id=120&cp_id=12001&cs_id=1082708&p_id=15276&seq=1&format=2

WEEE Information

User Information for Consumer Products Covered by EU Directive 2012/19/EU on Waste Electric and Electronic Equipment (WEEE)

This document contains important information for users with regards to the proper disposal and recycling of Monoprice products. Consumers are required to comply with this notice for all electronic products bearing the following symbol:



Environmental Information for Customers in the European Union

European Directive 2012/19/EU requires that the equipment bearing this symbol on the product and/or its packaging must not be disposed of with unsorted municipal waste. The symbol indicates that this product should be disposed of separately from regular household waste streams. It is your responsibility to dispose of this and other electric and electronic equipment via designated collection facilities appointed by the government or local authorities. Correct disposal and recycling will help prevent potential negative consequences to the environment and human health. For more detailed information about the disposal of your old equipment, please contact your local authorities, waste disposal service, or the shop where you purchased the product.



To prevent possible hearing damage, do not listen at high volume levels for long periods.

The Bluetooth® word mark and logos are registered trademarks of Bluetooth SIG, Inc.

IOS® is a trademark or registered trademark of Cisco in the U.S. and other countries and is used under license.