

MONOPRICE

Blackbird 4K USB-Powered 1x2 HDMI Splitter

P/N 15651

Quick Install Guide

SAFETY WARNINGS AND GUIDELINES

- This device is intended for indoor use only.
- Do not expose this device to water or moisture of any kind. Do not place drinks or other containers with moisture on or near the device. If moisture does get in or on the device, immediately unplug it from the power outlet and allow it to fully dry before reapplying power.
- Clean using a soft, dry cloth only. Do not use chemical cleaners, solvents, or detergents. For stubborn deposits, moisten the cloth with warm water.
- This device has no user serviceable parts. Do not attempt to open, service, or modify this device.
- Ensure that all devices are powered off and unplugged before making any electrical connections.

INTRODUCTION

Thank you for purchasing this HDMI® Splitter! This splitter allows the simultaneous viewing of a single HDMI source on two displays. As a USB-powered device, it is ideal for use with a laptop or other portable device.

CUSTOMER SERVICE

The Monoprice Customer Service department is dedicated to ensuring that your ordering, purchasing, and delivery experience is second to none. If you have any problem with your order, please give us an opportunity to make it right. You can contact a Monoprice Customer Service representative through the Live Chat link on our website www.monoprice.com during normal business hours (Mon-Fri: 5am-7pm PT, Sat-Sun: 9am-6pm PT) or via email at support@monoprice.com

PACKAGE CONTENTS


Please take an inventory of the package contents to ensure you have all the items listed below. If anything is missing or damaged, please contact Monoprice Customer Service for a replacement.

1x USB-power 1x2 HDMI® Splitter


1x Micro USB Cable

1x Quick Install Guide

PRODUCT OVERVIEW



1. Power LED
2. Micro USB Power Port
3. HDMI Input
4. HDMI Input LED



5. HDMI Output 1
6. HDMI Output 1 LED
7. HDMI Output 2
8. HDMI Output 2 LED

INSTALLATION

1. Ensure that all devices are unplugged and powered off before making any connections.
2. Using a High Speed HDMI® cable (not included), plug one end to the HDMI input of the first display, then plug the other end into the **HDMI Output 1** port on the splitter.
3. Using a High Speed HDMI cable (not included), plug one end to the HDMI input of the first display, then plug the other end into the **HDMI Output 2** port on the splitter.
4. Using a High Speed HDMI cable (not included), plug one end into the **HDMI Input** port on the splitter, then plug the other end into the HDMI output of your video source.
5. Plug one end of the included Micro USB cable into the **Power** port on the splitter, then plug the other end into the output of your USB power source.
6. Plug in and power on all connected devices.
7. The **Power LED** will illuminate when the splitter is connected to a live USB power source. The **HDMI Input LED** will illuminate whenever the splitter is powered on and an HDMI signal is present. The **HDMI Output LEDs** illuminate when the splitter is powered on, the corresponding output display is powered on, and an HDMI signal is present.

TECHNICAL SUPPORT

Monoprice is pleased to provide free, live, online technical support to assist you with any questions you may have about installation, setup, troubleshooting, or product recommendations. If you ever need assistance with your new product, please come online to talk to one of our friendly and knowledgeable Tech Support Associates. Technical support is available through the online chat button on our website www.monoprice.com during regular business hours, 7 days a week. You can also get assistance through email by sending a message to tech@monoprice.com

TROUBLESHOOTING

- Q1. Video is present on only one of the output displays.
- A1. Check the input selection on the display. Verify the display is capable of displaying the video resolution of the HDMI source and reduce the video resolution of the video source, as necessary. Check the HDMI cable connections. Try swapping out the HDMI cable with a known good one.
- Q2. There is no video on either output display.
- A2. Verify that the video source is powered on and that video is being played. Verify that the Power LED is illuminated. Verify that the two displays are capable of displaying the video resolution of the HDMI source and reduce the video resolution of the video source, as necessary. Check the HDMI cable connections. Try swapping out the HDMI cable with a known good one.
- Q3. The Power LED is not illuminated.
- A3. Verify that the USB power source is operating properly. Try using a different USB power source. Check the USB cable connections. Try swapping out the USB cable with a known good one.

SPECIFICATIONS

Model	15651
HDMI® Inputs	1
HDMI Outputs	2
Maximum Video Resolution	4K@30Hz
HDMI Version	1.4
HDCP Version	1.4
Power Source	Micro USB, 5 VDC