

MONOPRICE

BitPath AV™ SDI Extender over Single Cat6 Cable, 120m

P/N 16227

User's Manual

SAFETY WARNINGS AND GUIDELINES

Please read this entire manual before using this device, paying extra attention to these safety warnings and guidelines. Please keep this manual in a safe place for future reference.

- This device is intended for indoor use only.
- Do not expose this device to water or moisture of any kind. Do not place drinks or other containers with moisture on or near the device. If moisture does get in or on the device, immediately unplug it from the power source and allow it to fully dry before reapplying power.
- Do not touch the device, the power cord, or any other connected cables with wet hands.
- Do not expose this device to excessively high temperatures. Do not place it in, on, or near heat sources, such as a fireplace, stove, radiator, etc. Do not leave it in direct sunlight.
- Prior to operation, check the units and power adapters for physical damage. Do not use if physical damage has occurred.
- Take care to prevent damage to the power cord. Do not allow it to become crimped, pinched, walked on, or become tangled with other cords. Ensure that the power cord does not present a tripping hazard.
- Never unplug the unit by pulling on the power cord. Always grasp the connector head or adapter body.
- Ensure that power is turned off and disconnected before making any electrical connections.
- Clean using a soft, dry cloth only. Do not use chemical cleaners, solvents, or detergents. For stubborn deposits, moisten the cloth with warm water.
- This device has no user serviceable parts. Do not attempt to open, service, or modify this device.

INTRODUCTION

Thank you for purchasing this BitPath AV™ SDI Extender Kit! This extender transmits an SD-SDI, HD-SDI, or 3D-SDI video signal to distances up to 394 feet (120 meters) over a single Cat6 Ethernet cable. It supports resolutions up to 1080p@60Hz and uses the BitPath AV™ transmission protocol.

FEATURES

- Transmits an SD-SDI, HD-SDI, or 3D-SDI video signal to distances up to 394 feet (120 meters) over a single Cat6 Ethernet cable
- Supports resolutions up to 1080p@60Hz
- Uses the BitPath AV™ transmission protocol

CUSTOMER SERVICE

The Monoprice Customer Service department is dedicated to ensuring that your ordering, purchasing, and delivery experience is second to none. If you have any problem with your order, please give us an opportunity to make it right. You can contact a Monoprice Customer Service representative through the Live Chat link on our website www.monoprice.com during normal business hours (Mon-Fri: 5am-7pm PT, Sat-Sun: 9am-6pm PT) or via email at support@monoprice.com

PACKAGE CONTENTS


Please take an inventory of the package contents to ensure you have all the items listed below. If anything is missing or damaged, please contact Monoprice Customer Service for a replacement.



1x Transmitter



1x Receiver



2x AC Power Adapters



1x IR Transmitter



1x IR Receiver



1x User's Manual


PRODUCT OVERVIEW

Front Panels




1. **Power LED:** Illuminates when power is applied.
2. **Data Transmission LED:** The LED flashes slowly when a connection is being established, then flashes rapidly when successfully connected and transmitting data.
3. **Connection LED:** The LED illuminates when there is a solid connection with the receiver.

Transmitter Rear Panel




1. **DC 5V:** DC barrel connector for attaching the included AC power adapter.
2. **Reset:** Button for restarting the transmitter.
3. **BitPath AV™ TX:** RJ45 connector for attaching the Ethernet cable.
4. **IR Out:** 3.5mm jack for connecting the IR transmitter.
5. **SDI Input:** BNC connector for connecting the video source device.

Receiver Rear Panel



1. **DC 5V:** DC barrel connector for attaching the included AC power adapter.
2. **Reset:** Button for restarting the receiver.
3. **BitPath AV™ RX:** RJ45 connector for attaching the Ethernet cable.
4. **IR In:** 3.5mm jack for connecting the IR receiver.
5. **SDI Output:** BNC connector for connecting the video display.

INSTALLATION AND OPERATION



Perform the following steps to connect the BitPath AV™ system:

1. Place or mount the transmitter and receiver in their desired locations.
2. Using an RG-6 coaxial cable with BNC connectors (not included), plug one end into the SDI input on your display, then plug the other end into the **SDI Output (5)** connector on the receiver.
3. Plug the included IR Receiver into the **IR In (4)** jack on the receiver, then position the IR receiver bulb in a position so that it can receive IR signals from your remote control.
4. Using an RG-6 coaxial cable with BNC connectors (not included), plug one end into the **SDI Input (5)** connector on the transmitter, then plug the other end into the SDI output on your video source device.
5. Plug the included IR Transmitter into the **IR Out (4)** jack on the transmitter, then position the IR emitter bulb in a position where it can transmit IR signals to the video source device.
6. Using an Ethernet cable wired to the TIA/EIA-568B standard, plug one end into the **BitPath AV™ RX (3)** jack on the receiver, then plug the other end into the **BitPath AV TX (3)** jack on the transmitter.
7. Plug the DC barrel connector on the other AC power adapter into the **DC 5V (1)** jack on the receiver, then plug the adapter into a nearby AC power outlet. The **Power LED (1)** on the receiver front panel will illuminate.
8. Plug the DC barrel connector on one of the AC power adapters into the **DC 5V (1)** jack on the transmitter, then plug the adapter into a nearby AC power outlet. The **Power LED (1)** on the transmitter front panel will illuminate. At the same time

the **Data Transmission LED (2)** on both the transmitter and receiver front panel will start flashing slowly to indicate that a connection is being established. Once the connection is completed, the **Connection LED (3)** on each unit will illuminate.

9. Start playing video content on your video source device. As data is being transmitted, the **Data Transmission LED (2)** on each device will start flashing rapidly, indicating that data is being transmitted and received. Verify that video is being displayed on your remote monitor.
10. Use your video source device's remote control at the remote television to verify that you can control the video source device from the remote location.

Congratulations, your BitPath AV™ system is now installed and ready for use!

TROUBLESHOOTING

Q1: The television only shows "waiting for connection" in the bottom right corner.

A1: Verify that the AC adapters for both the transmitter and receiver are plugged in and that the **Power LED (1)** on each unit is illuminated. Try swapping out the SDI cable with a known good one.

Q2: The television displays "Please check the TX input signal".

A2: Verify that the video source device is playing video content. Try swapping out the SDI cable between the video source device and the transmitter with a known good one. Try connecting the video source device directly to the television to verify that it is transmitting video. Verify that the video resolution on the video source does not exceed the 1080p@60Hz limit of the system.

Q3: The video on the television is unstable.

A3: Press the **Reset (2)** button on each unit to allow them to reestablish a connection. Ensure that the Ethernet cable is within the length limits for its type. Try using a higher category Ethernet cable. Replace the Ethernet cable with a known good one.

TECHNICAL SUPPORT

Monoprice is pleased to provide free, live, online technical support to assist you with any questions you may have about installation, setup, troubleshooting, or product recommendations. If you ever need assistance with your new product, please come online to talk to one of our friendly and knowledgeable Tech Support Associates.

Technical support is available through the online chat button on our website

www.monoprice.com during regular business hours, 7 days a week. You can also get assistance through email by sending a message to **tech@monoprice.com**

SPECIFICATIONS

Model	16227
Video Standard	SD-SDI, HD-SDI, 3D-SDI
Maximum Video Resolution	1080p@60Hz
Transmission Protocol	BitPath AV™
Maximum Transmission Distance	394 feet (120 meters) using Cat6 cable 328 feet (100 meters) using Cat5e cable 262 feet (80 meters) using Cat5 cable
IR Extender Bandwidth	20 ~ 60 kHz
Maximum Power Consumption (each)	6 watts
Power Source	5 VDC, 2A AC power adapters
Operating Temperature	+32 ~ +140°F (0 ~ +60°C)
Dimensions (each)	5.4" x 3.5" x 0.9" (138 x 105 x 24 mm)
Transmitter Weight	6.4 oz. (182g)
Receiver Weight	6.3 oz. (180g)

REGULATORY COMPLIANCE

Notice for FCC



This device complies with Part 15 of the FCC rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Modifying the equipment without Monoprice's authorization may result in the equipment no longer complying with FCC requirements for Class B digital devices. In that event, your right to use the equipment may be limited by FCC regulations, and you may be required to correct any interference to radio or television communications at your own expense.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Notice for Industry Canada

This Class B digital apparatus complies with Canadian ICES-003.

Cet appareil numérique de la classe B est conforme à la norme NMB-003 du Canada.