
Self-Tapped Mounting

. •



Locate the optimum location for the mounting plate and use it as a template to mark the drilling locations.
 NOTE: Do not drill or screw into the speaker where you could possibly damage the internal components.
 Drill the pilot hole(s) using a 1/8" drill bit. This hole(s) should not be drilled more than 1/2" depth (Figure 6).

MOUNTING TO THE WALL OR CEILING

The mounting hardware for three different surface applications is supplied. You will need to determine what style hardware will work best with your mounting surface. Always use caution when drilling into a wall or ceiling. Make sure to avoid all electrical and water lines.




Figure 7

DRYWALL SURFACE

on the mounting surface.

ceiling surface (Figure 8).

in a vertical pattern.

WOOD SURFACE

- 1. Using a stud finder, locate the wood stud or framing member.
- NOTE: Always mount the speakers in the center of a stud. 2. Using the wall plate as a template, mark hole positions
- on mounting surface. NOTE: Inwall mounting applications position mounting
- holes in a vertical pattern (Figure 7). 3. Drill holes through the drywall and into the wood stud
- using a 1/8" drill bit. These holes should be drilled 1-7/8" deep (Figure 7).
- 4. After the holes are drilled, mount the wall plate using the $#12 \times 1-3/4"$ self tapping screws.




Figure 9

Use hammer to tap anchor into place

Extension Mounting

Ceiling and/or Shelf Applications
Do Not Use
Extension In
Wall Mounted
Applications
Tighten the Allen screw using
the provided Allen wrench

Figure 10

Install 2-1/2" extension portion of the speaker mount to the wall plate.

Secure the setscrew to hold the extension in place with the weight of the speaker attached.

CONCRETE SURFACE

1. Using the wall plate as a template mark a hole positions on the mounting surface.

- NOTE: In wall mounting applications position mounting holes in a vertical pattern.
- Drill holes in the solid concrete or hollow block using a 5/16" masonry bit. Once the holes are drilled, insert the #12-14 Alligator anchors (Figure 9) into the holes, making sure the anchor is flush with the surface of the wall (Figure 9).

1. Locate the best mounting location in the ceiling or wall.

NOTE: In wall mounting applications position mounting holes

 Drill holes in the drywall using a 5/16" drill bit (Figure 8).
 Once the holes are drilled, insert the alligator anchor into the holes. Make sure the anchor is flush with the wall and/or

4. With the anchors in place, mount the wall plates using the

Using the wall plate as a template, mark the hole positions

3. With the wall anchors in place, mount the wall plate using the $#12 \times 1-3/4$ " self tapping screws (Figure 9).


#12 x 1-3/4" self tapping screws (Figure 8).



Tighten the Allen screw using the provided Allen wrench

Figure 11

Install the low-profile portion of the speaker mount to the wall plate or 2-1/2" extension. Secure the setscrew to hold the extension in place with the weight of the speaker attached.



Post Style Speaker Plate 2-Hole Speaker Plate Figure 12 Install the speaker with the speaker post or

2-hole plate attached. Secure the setscrew to hold the extension in

place with the weight of the speaker attached.