




Monoprice™ 6-in-1 USB-C
Portable Folding Laptop Docking Station Stand

P/N **44735**
User Manual

SAFETY WARNINGS AND GUIDELINES

Please read this entire manual before using this device, paying extra attention to these safety warnings and guidelines. Please keep this manual in a safe place for future reference.

- This device is intended for indoor use only.
- Do not expose this device to water or moisture of any kind. Do not place drinks or other containers with moisture on or near the device. If moisture does get in or on the device, immediately unplug it from the power source and allow it to fully dry before reapplying power.
- Do not touch the device, the power cord, or any other connected cables with wet hands.
- Do not expose this device to excessively high temperatures. Do not place it in, on, or near heat sources, such as a fireplace, stove, radiator, etc. Do not leave it in direct sunlight.
- Do not place or install this device in an area where it can be exposed to excessive amounts of dust, humidity, oil, smoke, or combustible vapors.
- Prior to operation, check the unit and power cord for physical damage. Do not use if physical damage has occurred.
- Before plugging the unit into a power outlet, ensure that the outlet provides the same type and level of power required by the device.
- Unplug this device from the power source when not in use.
- Take care to prevent damage to the power cord. Do not allow it to become crimped, pinched, walked on, or become tangled with other cords. Ensure that the power cord does not present a tripping hazard.
- Never unplug the unit by pulling on the power cord. Always grasp the connector head or adapter body.
- Ensure that power is turned off and disconnected before making any electrical connections.
- Clean using a soft, dry cloth only. Do not use chemical cleaners, solvents, or detergents. For stubborn deposits, moisten the cloth with warm water.
- This device has no user-serviceable parts. Do not attempt to open, service, or modify this device.


Table of Contents

<i>Introduction</i>	<i>3</i>
<i>Ports and connectors</i>	<i>4</i>
<i>Please Follow the Steps Below to Properly Use Your Dock.....</i>	<i>5</i>
<i>Supports Extend & Mirror Mode</i>	<i>5</i>
<i>Troubleshooting</i>	<i>6</i>

Introduction

Thank you for your purchase of the Monoprice 6-in-1 USB-C Portable Folding Laptop Docking Station Stand. This docking station stand can help to expand your laptop with full-feature USB-C ports to 4K HDMI, 2 USB 3.0, Type C 3.0, Type C Host, and RJ45 Gigabit Ethernet, so you can easily connect multi devices via one USB-C cable. This docking station stand will help to save your valuable desktop space and improve your work efficiency.


Ports and connectors



- ① RJ45 Ethernet Port: Supports 10/100/1000 Mbps
- ② USB 3.0 Port: Support data transfer at speeds up to 5Gbp/s
- ③ HDMI Port: Connect to a device with an HDMI port to stream video at resolutions up to 4K 3840x2160@30Hz
- ④ Type-C 3.0 Port: Charger your laptop through the Type-C port, supports 100W power delivery. Support data transfer at speeds up to 5Gbp/s
- ⑤ Type-C Host: Connect to your Full-feature USB-C laptop

Note: This laptop dock stand only can work for Full-feature USB-C laptops.

Please Follow the Steps Below to Properly Use Your Dock



Step 1: Please expand the laptop dock stand left and right, adjust the product to the appropriate height.

Step 2: Please plug the power adapter into the Type-C 3.0 port (④).

Step 3: Please use the USB-C to USB-C data cable to connect the Type-C Host (⑤) interface of the laptop dock stand and the USB-C port of your laptop.

Step 4: Use a standard HDMI cable to connect the HDMI monitor via HDMI port(③).

Step 5: Attach USB 3.0 devices to the USB 3.0 ports of the dock(②).

Step 6: Connect the ethernet cable to the Ethernet port(①).

Supports Extend & Mirror Mode



Troubleshooting

Q: Is this docking station compatible with my laptop?

A: Please ensure the USB-C port of your laptop not only supports data transfer, but also supports Power Delivery and Alt-mode DisplayPort. If you are not sure, please contact Monoprice Technical Support.

Q: Why does my monitor not display via HDMI?

A: 1. Please ensure your laptop's USB-C port supports video output. Verify that the monitor has the correct HDMI input selected.

2. Please ensure that the cable is functional. Also verify the cable functionality, if using a conversion cable (HDMI to HDMI/DP/VGA cable).

3. Please attach the laptop's power supply to the Type-C 3.0 port of the docking station stand.

CUSTOMER SERVICE

The Monoprice Customer Service department is dedicated to ensuring that your ordering, purchasing, and delivery experience is second to none. If you have any problems with your order, please give us an opportunity to make it right. You can contact a Monoprice Customer Service representative through the Live Chat link on our website **www.monoprice.com** or via email at **support@monoprice.com**. Check the website for support times and links.

TECHNICAL SUPPORT

Monoprice™ is pleased to provide free, live, online technical support to assist you with any questions you may have about installation, setup, troubleshooting, or product recommendations. If you ever need assistance with your new product, please come online to talk to one of our friendly and knowledgeable Tech Support Associates. Technical support is available through the online chat button on our website **www.monoprice.com** or through email by sending a message to **tech@monoprice.com**. Check the website for support times and links.

To download the latest drivers, firmware, manuals, etc., go to **www.monoprice.com** and type **44735** into the search bar. If available, support files are linked at the bottom of the product page.

REGULATORY COMPLIANCE

Notice for FCC



This device complies with Part 15 of the FCC rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Modifying the equipment without Monoprice's authorization may result in the equipment no longer complying with FCC requirements for Class B digital devices. In that event, your right to use the equipment may be limited by FCC regulations, and you may be required to correct any interference to radio or television communications at your own expense.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Notice for ISED Canada

This Class B digital apparatus complies with Canadian ICES-003.

Cet appareil numérique de la classe B est conforme à la norme NMB-003 du Canada.

Disposal and Recycling Information



The symbol indicates that this product should be disposed of separately from regular household waste streams. It is your responsibility to dispose of this and other electrical and electronics products via designated collection facilities appointed by the government or local authorities. Correct disposal and recycling will help prevent potential negative consequences to the environment and human health. For more detailed

information about the disposal of your unwanted product, please contact your local authorities, waste disposal service, or the shop where you purchased the product.

Monoprice™ and all Monoprice logos are trademarks of Monoprice Inc.

HDMI®, the HDMI Logo, and High-Definition Multimedia Interface are trademarks or registered trademarks of HDMI Licensing LLC in the United States and other countries.



TECHNOLOGY AT PRICES THAT MAKE SENSE

www.monoprice.com

Need Help? We're here for you!

Contact us: www.monoprice.com/contactus

Product pictures are for reference only.

Specifications described herein are subject to change without prior notification.

Monoprice™ and all Monoprice logos are trademarks of Monoprice Inc.

Copyright © 2023 Monoprice, Inc. All rights reserved.

Monoprice, Inc.

1 Pointe Drive, Suite 400

Brea, CA 92821 – USA

www.monoprice.com